

Vortex Blastair Part List



LOW TEMPERATURE	VORTEX 2	VORTEX 4	VORTEX 6
Description	Reference	Reference	Reference
piston disc LT	PIS2LT	PIS4LT	PIS6LT
T shape valve	TVALV2	TVALV4	TVALV6
compression coil spring galv.		COILSPR4	COILSPR6
Sleeve cylinder HT		SLCYL4HT	SLCYL6HT
Closing plate cast iron		CLPLA4LT	CLPLA6LT
Closing plate O' ring		FLAGACL4	FLAGACL6
Piston U support		PISUP4LT	PISUP6LT
Flat Gasket closing plate	FLAGACL2	FLAGACL4	FLAGACL6
U support bolt Kit		UBOLT4LT	UBOLT4LT
Seal Gasket	OGASK2	OGASK4	OGASK6
Bolts and nuts	BOLNU10L	BOLNU16L	BOLNU19L
Flat flange Gasket	FLAGA2	FLAGA4	FLAGA6
Pressure vessel	PREVE10/PREVE20	PREVE50 / PREVE100	PREVE100
VORTEX	V210LT / V220LT	V450LT / V4100LT	V6100LT
Pilot valve 3/2 HT	SOLVAHT	SOLVAHT	SOLVAHT
fitting 1"	FIT1	FIT1	FIT1
QRV 1" HT	QRV1HT	QRV1HT	QRV1HT
Check valve 1/4"	NOVA1/4	NOVA1/4	NOVA1/4
flexible braided hose 1/2 -1/4 (from stop valve to pilot valve)	HOS2000L	HOS2000L	HOS2000L
Pilot control unit HT	PCU2205LT	PCU2205LT	PCU2205LT
Isolation valve 1/2" F X F	STOVA12F	STOVA12F	STOVA12F
Drainage valve 1/2" F X M	STOVA12M	STOVA12M	STOVA12M
Dial manometer 0 -10 bar	MANO	MANO	MANO
Safety control unit HT	SACU	SACU	SACU
Elbow discharge tube HT	LTUBE2LT	LTUBE4LT	LTUBE6LT
Flange	FLANGE2	FLANGE4	FLANGE6
Flat Gasket	FLAGA2	FLAGA4	FLAGA6
Bolts and nuts	BOLNU16	BOLNU16	BOLNU19
Support plate 300 x 300 mm	REPLA300	REPLA300	REPLA300
Blowing pipe	PIP2LT	PIP4LT	PIP6LT
Safety release valve 8 bar	SAVA8	SAVA8	SAVA8
Suspension Safety Kit	SUSAK	SUSAK	SUSAK
Auto sequencing panel 8 units	SOLO8	SOLO8	SOLO8
Air FRL group unit 1"	AIRFIL1	AIRFIL1	AIRFIL1

**Last Updated: 10/2005